



PRUNE ONLY TO REMOVE ANY BROKEN, DEAD OR DISEASED WOOD WHILE PRESERVING FORM AND CHARACTER OF TREE; DO NOT CUT LEADER; DO NOT PRUNE TO REDUCE CANOPY SIZE.

THE ROOT FLARE SHALL BE PLANTED AT GRADE, NO HIGHER THAN 2" ABOVE GRADE, AND NEVER BELOW GRADE. REMOVE EXCESS SOIL TO EXPOSE THE ROOT FLARE AT GRADE. TREE SHALL BE SET PLUMB. .

MULCH DEPTH 3".
KEEP MULCH 3" FROM ROOT FLARE
AND DO NOT CONTACT STEM.

HIGH QUALITY SOIL MIX AS SPECIFIED IN TREE PLANTING NOTES 06.01.02

WATER SAUCER SHALL BE NO MORE THAN 3" ABOVE GRADE.

COMPLETELY REMOVE TOP HALF OF BURLAP; LACING AND WIRE BASKET AND DISCARD FROM HOLE.

ROOT BALL SHALL BE PLACED DIRECTLY ON COMPAKTED SUGRADERE. HANDLE TREE BY THE ROOT BALL ONLY.

REVISIONS	
NO.	DATE
1	4/22/25
	UPDATE TO CURRENT STANDARDS

Monroe
North Carolina

TYPICAL TREE PLANTING

FILE: I:\\Maps-Details\\Detail Manual\\Details
DRAWN BY: JAM
DATE: 08-07-01
CHECKED BY: JNL
SCALE: N.T.S.
PREPARED BY:
ENGINEERING DEPARTMENT
DETAIL 06.01.01